





Locate the steel pin on the backside of the shelf frame and insert into the crevice of the Twist extrusion upright



Hold the shelf frame at the required height and tighten the wing nuts to keep the shelf in place.



Before attaching the graphic to the Twist, make sure the rotatable arms are in this position.



When the Twist graphic has been attached, rotate the arms 900 so that they poke through the Twist graphic.



Locate the four magnetic disks on the underside of the wooden shelf.



The magnetic disks will magnetically attach to the shelf frame arms.